TT-DCAG5 Quick Guide

QUICK GUIDE FOR GTD 5 (DUAL SESSION) SWITCH ACCESS TERMINALS

CONTENTS:

GTD 5 SWITCH ACCESS TERMINAL CONFIGURATION ..... Page 1

TERMINAL COMMAND KEYS ..... Page 2

NUMERIC KEYPAD FUNCTIONS ..... Page 3

GENERAL SETTINGS NOTE ..... Page 4

TERMINAL SETUP ..... Page 5

CHANGING THE SERIAL PORT SETTINGS ..... Page 6

CHANGING THE SCREEN DISPLAY TO FULL OR SPLIT SCREEN ..... Page 7

PROGRAMMING FUNCTION KEYS ..... Page 8

CHANGING THE SCREEN TITLE ..... Page 9

GTD 5 DEFAULT SETUP ..... Page 10

TAG INC.
Telecom Assistance Group, Inc.
856-753-8585

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

GTD 5 SWITCH ACCESS TERMINAL CONFIGURATION

FIGURE 1



** PRESS THE AUTO BUTTON TWICE TO AUTOMATICALLY OPTIMIZE THE DISPLAY POSITION, FOCUS AND CLOCK OF YOUR DISPLAY.*

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

TERMINAL COMMAND KEYS

FIGURE 2



SWITCH SESSIONS (for dual sessions only)	Press **Ctrl + Enter** *(Enter on the Number Pad)* Ctrl + Num Lock / * - ; 7 Home 8 9 PgUp +; 4 5 6; 1 End 2 3 PgDn Enter; 0 Ins . Del
PRINT	Press **Ctrl + Shift + ●** *(Decimal on the Number Pad)* Ctrl + Shift + Num Lock / * - ; 7 Home 8 9 PgUp +; 4 5 6; 1 End 2 3 PgDn Enter; 0 Ins . Del
SEND BREAK	Press **Ctrl + Pause/Break Key** Ctrl + Pause Break

PF-1	The PF-1 key displays the ACDC Main Menu on the lower half of the ACDC terminal screen.
PF-2	The PF-2 key causes the system to accept the input characters.
PF-3	The PF-3 key cancels the current menu.
PF-4	The PF-4 key at both the local and remote ACDC terminal toggles control between terminals. If the terminal is inactive, the PF-4 key activates it; if it is active, pressing the PF-4 key deactivates it. Using this key overrides the remote transfer feature.

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

NUMERIC KEYPAD KEY FUNCTIONS

FIGURE 3

K0	Acknowledge Alarms
K1	Refresh Static Display
K2	Performance Monitor Display 2
K3	Performance Monitor Display 3
K4	Performance Monitor Display 4
K5	ACDC Configuration Menu
K6	Print This Help Panel
K7	Toggle IOM Mode
K8	Enter ScratchPad Mode
K9	Leave ScratchPad Mode

NOTE:
Some of the keys listed in FIGURE 3 are affected when a menu is in progress. PF2* and PF3* are valid only during menu processing, while PF1*, K5, K7, K8 and K9 are valid only when no menu is processing. The other keys - K0, K1, K2, K3, K4, K6 and PF4* are valid at all times.

**PF functions are on the previous page.*

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

GENERAL SETTINGS NOTE

Terminals are supplied pre-configured for your GTD 5 switch. Some local settings may need to be adjusted. Example: Baud Rate, Function Keys etc.

The following pages show how to make adjustments to the terminal when required.

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

TERMINAL SETUP

FIGURE 4



FIGURE 5



ENTER SETUP SCREEN	Press **Ctrl + Scroll Lock**
SELECT MENU	Press **F1 - Prt Scn** *(see pg.10 for GTD 5 Default Setup)*
NAVIGATE PARAMETERS	Press the **Arrow Keys**
NAVIGATE CHOICES	Press **Enter** or **Spacebar** (moves forward)
	Press **Shift + Enter** (moves backward)
EXIT SETUP SCREEN	Press the **Pause Key** (when prompted to "Save all", press **Y** key to **Save** or **N** key to **discard**)

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

CHANGING THE SERIAL PORT SETTINGS

FIGURE 6A



1. Press the **F1** button

FOR SESSION 1

2. Use the **Arrow Keys** to move to **SER1 Baud Rate (SER1 = Serial Port 1)**
3. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (9600 for GTD 5)
4. Use the **Arrow Keys** to move over to **SER1 Data Format**
5. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (8/1/N for GTD 5)
6. Press **<Control> <EnterKpd> to Toggle to Session 2** *(see page 2 - "Switching Sessions")*

FIGURE 6B



FOR SESSION 2

7. Use the **Arrow Keys** to move to **SER2 Baud Rate (SER2 = Serial Port 2)**
8. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (9600 for GTD 5)
9. When finished, press the **Pause Key** at the top right of the keyboard
10. When prompted with "**Save all?**", click **Y** to save the new **Parameters**

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

CHANGING THE SCREEN DISPLAY TO FULL OR SPLIT SCREEN*

***Note:** Applies to dual sessions only (see session setting in figures 6A & 6B).*

FIGURE 7



1. Press the **F2** button
2. Use the **Arrow Keys** to move over to **Session Display**
3. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (Full / Split)

FIGURE 8



4. Press the **F3** button
5. Use the **Arrow Keys** to move over to **Screen Length**
6. Press **Enter** or **Spacebar** until the correct **Choice** is highlighted (26 Lines for Full Screen)
   (49 Lines for Split Screen)
7. When finished, press the **Pause Key** at the top right of the keyboard
8. When prompted with "**Save all?**", click **Y** to save the new **Parameter**

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

PROGRAMMING FUNCTION KEYS*

Each function key has (4) programmable registers per session such as **F/key, sh-F/key, ctrl-F/key & ctrl-sh-F/key*
*(These can be selected from the "Choices" located in the **"Program"** Parameter)*

FIGURE 9



Note:
For ^ press Shift+6

1. Press the **F12** button
2. The curser will appear in the "Key" Field with F1 as the default **(<u>DO NOT</u> change F1-F4)**
3. Select a new function key to program by pressing **Enter** or **Spacebar** until the correct **Choice** is highlighted (for example choose F6)
4. Arrow down to move to the "Text" Field
5. Type in the "Function" for the key. *<u>CAUTION:</u> The first character in the Text Field cannot be left blank*

   Example: To program **ESC[17~** Type: **Shift+6** **[[17** **Shift+`** **= (^[[17~)**
6. To program another function, arrow back up to the "Key" Field & repeat steps 3-5
7. When finished, press the **Pause Key** at the top right of the keyboard
8. When prompted with "**Save all?**", click **Y** to save the new **Parameter**

<u>DO NOT CHANGE THE FUNCTIONS OF F1, F2, F3 & F4</u>

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

CHANGING THE SCREEN TITLE

Note: *This will change the title at the top of each Session.*

FIGURE 10A



1. Press the **F11** button

FOR SESSION 1

2. Use the **Arrow Keys** to move the curser down to **Screen Title**
3. Type in a Title for Session 1 (Example: TT-DCAG5 1)
4. Press **<Control> <EnterKpd> to Toggle to Session 2** *(see page 2 - "Switching Sessions")*

FIGURE 10B



FOR SESSION 2

5. Use the **Arrow Keys** to move the curser down to **Screen Title**
6. Type in a Title for Session 2 (Example: TT-DCAG5 2)
7. When finished, press the **Pause Key** at the top right of the keyboard
8. When prompted with "**Save all?**", click **Y** to save the new **Parameters**

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com

TT-DCAG5 Quick Guide

GTD 5 DEFAULT SETUP*

***Note:** Items in **Bold** may require Local Settings.*

***Note:** When using Dual Sessions, parameters must be set for both sessions.*

FIGURE 11

Menu	Key	Parameters Available (Not all will display for a given emulation, keyboard, or video mode)		
Quick	**F1**	Emulation = VT-300-7 Comm Mode = Full Duplex Enhanced = On Host/Printer = SER1/Para SER2/Para	**SER1 Baud Rate = 9600** SER2 Baud Rate = 9600 Language = U.S.	**SER1 Data Format = 8/1/N** SER2 Data Format = 8/1/N Sessions = Two
General	**F2**	Emulation = VT-300-7 Screen Saver = 5-min Warning Bell = On Host/Printer = SER1/Para SER2/Para	Enhanced = On Auto Page = Off Bell Length = 350 ms Sessions = Two	Auto Wrap = Off Auto Scroll = Off Bell Volume = 5 Session Display=Full
Display	**F3**	Page Length = 24 Display Cursor = On Columns = 80	Screen Length = 26 Lines Cursor = Blink Block Erase Color = Black	Screen Video = Normal Auto Adjust Cursor = On Scroll Speed = Full
Keyboard	**F4**	Language = U.S. Key Click = Off **Num Lock = Toggle**	Char Set Mode = ANSI Key Repeat = On Key Lock = Reverse	Margin Bell = Off Key Rate = 20 cps Caps Lock = Toggle
Keys	**F5**	Enter Key = <CR> Alt Key = Compose UDKS = Emul Dependent	Return Key = <CR> Disconnect = Pause	Backspace = <BS>/<DEL> Return Key Repeat = Off
Ports	**F6**	SER1 Baud Rate = 9600 SER2 Baud Rate = 9600 SER1 Xmt = Xon-Xoff SER2 Xmt = Xon-Xoff SER1 Break = 250 ms SER2 Break = 250 ms	SER1 Data Format = 8/1/N SER2 Data Format = 8/1/N SER1 Recv = Xon-Xoff(XPC) SER2 Recv = Xon-Xoff(XPC) SER1 Modem Control = Off SER2 Modem Control = Off	SER1 Parity Check = Off SER2 Parity Check = Off SER1 Xmt Pace = Baud SER2 Xmt Pace = Baud SER1 Disconnect = 2 sec SER2 Disconnect = 2 sec
Host	**F7**	Comm Mode = Full Duplex Recv <DEL> = Ignore Send Region = Screen	Local = Off Null Suppress = On Send End = Region	Recv <CR> = <CR> Send Block Term = None
Print	**F8**	Prnt Mode = Normal	Prnt Region = Screen	Prnt Block = None
Emulation	**F9**	Numeric Kpd = Application ANSI-ID = VT320 Status Line = Indicator	Cursor Kpd = Application Feature Lock = Off	Send Data = All Function Key Lock = Off
Tabs	**F10**	Auto Init Tabs = Off	Default Tabs	
Answerback	**F11**	Answerback Mode = On Answerback Message: /VT-100/	Answerback Conceal	
Program	**F12**	Key = F6 Text: ^[[17~	Program = F/Key	Key Dir = Comm Dependent
Execute	**Prt Sc**	Save Terminal Save Session Reset Terminal Clear Screen Terminal Version	Recall Terminal Recall Session Reset Session Default Session UDKS	Default Terminal Default Session Reset Ports Update Terminal
Exit Setup	**Pause**	Save all? (Y/N)		

SER1 = SERIAL PORT 1 SER2 = SERIAL PORT 2

Copyright© 2014 by Telecom Assistance Group, Inc. / Phone: (856) 753-8585 / Fax: (856) 768-7645 / www.tagcords.com