

CAUTION:

DO NOT look directly into the laser or point at anyone to avoid eye damage!!

Key Details on TFS-210A / TFS-208 Auto Shut-off:

- **Default Timing:** Visual Fault Locator will automatically turn off after 15 minutes of no operation.
- **Deactivate Function:** Press & hold the power button while turning on the unit until the LED indicator flashes three times, indicating the auto-off function is disabled.
- **Auto-off Function** will stay disabled if unit turned off.
- **Reset to Default:** Press & hold power button. The LED indicator will flash 5 times, indicating the **unit has reset**.
- **Removing Batteries will reset the unit to default timing.**

TAG, INC.

www.tagcords.com

856-753-8585