












Frontier Coax Cables & Loopback Tools

FEATURES / APPLICATION	FTR UPN #	DESCRIPTION
<p>Dual 440D to Dual 440D w/ Tracer, (5')</p> <ul style="list-style-type: none"> A convenient way of patching Tx & Rx circuits at the same time 	<p>400440DD-05</p>	<p>DUAL 440D to DUAL 440D w/ TRACER</p> 
<p>Dual BNC to Dual BNC w/ Tracer, (3') Dual BNC to Dual BNC w/ Tracer, (9') Dual BNC to Dual BNC w/ Tracer, (35') Dual BNC to Dual BNC w/ Tracer, (45')</p> <ul style="list-style-type: none"> Patch cord used with DSX-3/4 	<p>400440BB-03 400440BB-09 400440BB-35 400440BB-45</p>	<p>DUAL BNC to DUAL BNC w/ TRACER</p> 
<p>440A to BNC - Red, (8') 440A to BNC - Red, (14') 440A to BNC - Blue, (14')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400440BRD-08 400440BRD-14 400440BBL-14</p>	<p>440A to BNC</p> 
<p>440A to 440A, (9'') 440A to 440A - Black, (8') 440A to 440A, (15')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400440A-01 400440ABK-08 400440A-15</p>	<p>440A to 440A</p> 
<p>440A to 358A - Black, (8') 440A to 358A - Red, (8') 440A to 358A, (15')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>440358ABK-08 440358ARD-08 440358A-15</p>	<p>440A to 358A</p> 
<p>358A to 358A, (9'')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400358A-01</p>	<p>358A to 358A</p> 

Frontier Coax Cables & Loopback Tools

FEATURES / APPLICATION	FTR UPN #	DESCRIPTION
<p>440A (male) to 440A (male) Loopback Cord, (8")</p> <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440A-R8	<p>440A (male) LOOPBACK CORD</p> 
<p>440D Loopback Plug (molded)</p> <ul style="list-style-type: none"> 440D Loopback plug 	400440DLM	<p>440D LOOPBACK PLUG (molded)</p> 
<p>440 (female) to 440 (female) Loopback Cord, (8")</p> <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440FLP-01	<p>440 (female) LOOPBACK CORD</p> 
<p>440 (female) to 440 (female) Loopback Tool</p> <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440LPT	<p>440 (female) LOOPBACK TOOL</p> 
<p>BNC (female) to BNC (female) Loopback Tool</p> <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400600LPT	<p>BNC (female) LOOPBACK TOOL</p> 
<p>Mini-SMB Coax Loopback Tool (female / male)</p> <ul style="list-style-type: none"> Used to verify Mini-SMB coax cabling when extending FITL equipment 	400632LPT	<p>MINI-SMB COAX LOOPBACK TOOL</p> 