






FEATURES / APPLICATION	FTR UPN #	DESCRIPTION
<p>Dual 440D to Dual 440D w/ Tracer, (5')</p> <ul style="list-style-type: none"> A convenient way of patching Tx & Rx circuits at the same time 	<p>400440DD-05</p>	<p>DUAL 440D to DUAL 440D w/ TRACER</p> 
<p>Dual BNC to Dual BNC w/ Tracer, (3') Dual BNC to Dual BNC w/ Tracer, (9') Dual BNC to Dual BNC w/ Tracer, (35') Dual BNC to Dual BNC w/ Tracer, (45')</p> <ul style="list-style-type: none"> Patch cord used with DSX-3/4 	<p>400440BB-03 400440BB-09 400440BB-35 400440BB-45</p>	<p>DUAL BNC to DUAL BNC w/ TRACER</p> 
<p>440A to BNC - Red, (8') 440A to BNC - Red, (14') 440A to BNC - Blue, (14')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400440BRD-08 400440BRD-14 400440BBL-14</p>	<p>440A to BNC</p> 
<p>440A to 440A, (9") 440A to 440A - Black, (8') 440A to 440A, (15')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400440A-01 400440ABK-08 400440A-15</p>	<p>440A to 440A</p> 
<p>440A to 358A - Black, (8') 440A to 358A - Red, (8') 440A to 358A, (15')</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>440358ABK-08 440358ARD-08 440358A-15</p>	<p>440A to 358A</p> 
<p>358A to 358A, (9")</p> <ul style="list-style-type: none"> Coax Patch/Test Cord 	<p>400358A-01</p>	<p>358A to 358A</p> 