## **CENTRAL OFFICE**

FEATURES / APPLICATION	PART#	DESCRIPTION
<ul> <li>D4 (4W Looping Plug)</li> <li>Plugs into a 4 wire voice frequency channel unit</li> <li>Loops both ways for testing TX/RX levels</li> </ul>	400488LP	D4 (4W LOOPING PLUG)  4W
15 Pin (male) to LIU connector, (8')	400442M	15 PIN to LIU
<ul> <li>15 Pin (female) to LIU connector, (8')</li> <li>Connects Power Panel to LIU for test jack access</li> </ul>	400442F	SEGREGAL SEG
D4 Monitor Cord, (5')	400480MHS	D4 MONITOR PLUG to 471A PLUG
<ul> <li>Access dial tone from FXS and FXO cards</li> </ul>		DIRECTIONAL SWITCH
<ul> <li>Directional switch enables dial tone to be pulled from the far end when plugged into the FXS card or near end (SMAS/Frame) when plugged into the FXO card</li> </ul>		MONITOR O/H TESTING PINS 1 & 2 PINS 5 & 6 TO T & R TO T & R
D4 Plug to Dual 310, (6')	<b>T-P6AD-06</b> (102 822 459)	D4 PLUG to DUAL 310
D4 Plug to Dual 310, (12')	<b>T-P6AD-12</b> (102 822 467)	
<ul> <li>Replacement cord for D3/D4 WECO CAU test set and the Sierra 431 Channel Unit Extender test set</li> </ul>		
D4 Plug to 310 "Y" (Line) / 310 "Y" (Drop), (6')	400480LP	D4 PLUG to 310 "Y" (LINE) / 310 "Y" (DROP)
<ul> <li>Used with transmission test sets to measure (-8.5) transmit and (+4) recieve levels at D4 Channel Unit</li> </ul>		TX LINE  RX DROP  RX DROP

Copyright © 2025 by Telecom Assistance Group, Inc.

150 Cooper Rd. (F-15) W. Berlin, NJ 08091 2025 Catalog\Sec-03\pg09\_r16.dsf (10/15/25)

Telephone: (856) 753-8585 Fax: (856) 768-7645