


CENTRAL OFFICE

Page 17

FEATURES / APPLICATION	PART #	DESCRIPTION
800 DSX (male) to 310 (female), (12") Plug 310 into female 310 converts to 800 DSX	408238-12	800 DSX (male) to 310 (female) 
800 DSX (male) to Bantam (female), (2') Plug Bantam into female Bantam converts to 800 DSX	408210F	800 DSX (male) to BANTAM (female) 
800 DSX Terminating Plug 100 ohm Termination	408800TP-1	800 DSX TERMINATING PLUG 
800 DSX Looping Plug 800 DSX Looping Plug - PN # 408800LP "Loops" in ONE Direction - PN # 408800LD "Loops" in BOTH Directions	408800LP 408800LD	800 DSX LOOPING PLUG 
800 DSX Pass Thru Plug Used to keep 800 DSX circuits closed	400800PTM	800 DSX PASS THRU PLUG 