


# DMS/100/10 Current Loop Adapters & Accessories

**PN # 400725SB2**

RS-232 to DMS/100/10, DB25M, Current Loop Adapter


[VZ ID # 1105 6852](#)



**PN # 400725SB**

RS-232 to DMS/100/10, Current Loop Adapter

[VZ ID # 1105 5513](#)



## Application:

TAG's Current Loop Adapters (PN# 400725SB & 400725SB2) are used to program and troubleshoot a DMS. The Hardwire Adapter (PN # 400725SBW) connects the TX (+/-) and RX (+/-) current loop wires to a 25 Pin female connector. It is used with the 400725SB2 Current Loop Adapter when the DMS 100/10 System doesn't have a DEC connector.



**PN # 400725LB**  
DB25M to DB25F Mini Tracer  
[VZ ID # 1128 5345](#)



**PN # 400709LB**  
DB9M to DB9F Mini Tracer  
[VZ ID # 1128 5344](#)

## Ordering Information:

|            |   | <b>VZ ID #</b> |
|------------|---|----------------|
| 400725SB   | RS-232 to DMS/100/10 Current Loop Adapter   | 1105 5513      |
| 400725SB2  | RS-232 to DMS/100/10, DB25M Current Loop Adapter                                  | 1105 6852      |
| 400725SBW  | Hardwire Adapter for 400725SB2  | 1118 2236      |
| 400725LB   | DB25M to DB25F Mini Tracer  | 1128 5345      |
| 400709LB   | DB9M to DB9F Mini Tracer  | 1128 5344      |
| 400725NL   | DB25F to DB25M (Orange) Null Adapter (not shown)                                  | 1128 5343      |
| 400721D-12 | DMS Interface Cord, Dual Bantam to DB25F, (12') (used with 400725SB2) (not shown) | 1105 6851      |
| 400725SBPS | Power Supply for 400725SB/2 (optional - not shown)                                | 1118 2238      |
| T-DMSTBT   | DMS-10/100 Pre-Charge Tool (not shown)  | 1132 1287      |
| TT-DCA5-PP | Replacement Power Pack for Single/Dual Session Terminals, 5VDC (not shown)        | 1136 2015      |

150 Cooper Rd. (F-15)  
W. Berlin, NJ 08091

[www.tagcords.com](http://www.tagcords.com)  
**Telecom Assistance Group**

Telephone: (856) 753-8585  
Fax : (856) 768-7645