











FEATURES / APPLICATION	PART #	VZ ID #	DESCRIPTION
<p>440D to 440D w / Tracer, (10')</p> <p>440D to 440D w / Tracer, (16')</p> <ul style="list-style-type: none"> Used for loop-back or patching Available in various lengths 	<p>400440D-10</p> <p>400440D-16</p>	<p>8722 0617</p> <p>1125 8969</p>	<p>440D to 440D w/ TRACER</p> 
<p>Dual 440D to Dual BNC w/ Tracer, (6')</p> <p>Dual 440D to Dual BNC w/ Tracer, (10')</p> <p>Dual 440D to Dual BNC w/ Tracer, (12')</p> <p>Dual 440D to Dual BNC w/ Tracer, (20')</p> <p>Dual 440D to Dual BNC w/ Tracer, (30')</p> <ul style="list-style-type: none"> Used for DSX-3/4 with commercial DSX-3 frames that have BNC jacks for cross-connections 	<p>400440DR-06</p> <p>400440DR-10</p> <p>400440DR-12</p> <p>400440DR-20</p> <p>400440DR-30</p>	<p>8726 9855</p> <p>1108 9984</p> <p>1105 2058</p> <p>1108 9985</p> <p>1108 9986</p>	<p>DUAL 440D to DUAL BNC w/ TRACER</p> 
<p>Dual LCC to Dual LCC w/ Tracer, (10')</p> <p>Dual LCC to Dual LCC w/ Tracer, (15')</p> <p>Dual LCC to Dual LCC w/ Tracer, (20')</p> <p>Dual LCC to Dual LCC w/ Tracer, (25')</p> <p>Dual LCC to Dual LCC w/ Tracer, (30')</p> <p>Dual LCC to Dual LCC w/ Tracer, (35')</p> <ul style="list-style-type: none"> REAR "locking" cross connection to ADC's Mini DSX 3/4 	<p>400470CC-10</p> <p>400470CC-15</p> <p>400470CC-20</p> <p>400470CC-25</p> <p>400470CC-30</p> <p>400470CC-35</p>	<p>1107 2246</p> <p>1107 2245</p> <p>1108 2290</p> <p>1108 2291</p> <p>1108 2292</p> <p>1108 2293</p>	<p>DUAL LCC to DUAL LCC w/ TRACER</p> 

Verizon Coax

FEATURES / APPLICATION	PART #	VZ ID #		DESCRIPTION
440A to 440A - Red, (8') 440A to 440A - Black, (8') <ul style="list-style-type: none"> Coax Patch/Test Cord 	400440ARD-08 400440ABK-08	1100 7951 1100 7950	Red Black	440A to 440A 
440A to 440A - Red, (6') 440A to 440A - Black, (6') <ul style="list-style-type: none"> Coax Patch/Test Cord 	400440ARD 400440ABK	1105 4723 1105 4724	Red Black	440A to 440A 
440A to BNC - Red, (8') 440A to BNC - Black, (8') <ul style="list-style-type: none"> Coax Patch/Test Cord 	400440BRD-08 400440BBK-08	1100 7953 1100 7952	Red Black	440A to BNC 
440A to 358A, (6') 440A to 358A - Red, (8') 440A to 358A - Black, (8') <ul style="list-style-type: none"> Coax Patch/Test Cord 	440358A-06 440358ARD-08 440358ABK-08	1125 8968 1100 7955 1100 7954	Red Black	440A to 358A 
BNC to BNC, (1') BNC to BNC, (50') <ul style="list-style-type: none"> General purpose test cord 	400600-01 400600-50	1104 1391 1106 7569	1' 50'	BNC to BNC 
BNC Coupler <ul style="list-style-type: none"> Extension for standard BNC (male) cords 	BNC-C	1125 8966		BNC COUPLER 


FEATURES / APPLICATION	PART #	VZ ID #	DESCRIPTION
440D Loopback Plug (molded) <ul style="list-style-type: none"> 440D Loopback plug 	400440DLM	1104 1393	440D LOOPBACK PLUG (MOLDED)
440D Loopback Plug <ul style="list-style-type: none"> 440D Loopback plug 	400440DLP	8725 1533	440D LOOPBACK PLUG
440A (Male) to 440A (Male) Loopback Cord, (8") 440A (Male) to 440A (Male) Loopback Cord, (1') <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440A-R8 400440A-01	1106 6212 1106 8273	440A (Male) LOOPBACK CORD
440 (Female) to 440 (Female) Loopback Cord, (8") <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440FLP-01	1100 7821	440 (Female) LOOPBACK CORD
440 (Female) to 440 (Female) Loopback Tool <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400440LPT	1100 7822	440 (Female) LOOPBACK TOOL
BNC (Female) to BNC (Female) Loopback Tool <ul style="list-style-type: none"> Allows a technician to verify the patch cord portion of a DS3 circuit under test 	400600LPT	1100 7823	BNC (Female) LOOPBACK TOOL

COAX PATCH CORDS



Ordering Information:

		VZ ID #
400440BB-01	Dual BNC to Dual BNC w/ tracer, (1')	1100 7839
400440BB-03	Dual BNC to Dual BNC w/ tracer, (3')	1100 7840
400440BB-05	Dual BNC to Dual BNC w/ tracer, (5')	1100 7841
400440BB-07	Dual BNC to Dual BNC w/ tracer, (7')	1100 7842
400440BB-09	Dual BNC to Dual BNC w/ tracer, (9')	1100 7843
400440BB-10	Dual BNC to Dual BNC w/ tracer, (10')	8721 0460
400440BB-11	Dual BNC to Dual BNC w/ tracer, (11')	1105 4902
400440BB-15	Dual BNC to Dual BNC w/ tracer, (15')	914370
400440BB-19	Dual BNC to Dual BNC w/ tracer, (19')	914374
400440BB-20	Dual BNC to Dual BNC w/ tracer, (20')	1108 9990
400440BB-25	Dual BNC to Dual BNC w/ tracer, (25')	8725 9527
400440BB-30	Dual BNC to Dual BNC w/ tracer, (30')	8728 1688
400440BB-35	Dual BNC to Dual BNC w/ tracer, (35')	1100 7846
400440BB-37	Dual BNC to Dual BNC w/ tracer, (37')	914393
400440BB-40	Dual BNC to Dual BNC w/ tracer, (40')	8721 0473
400440BB-45	Dual BNC to Dual BNC w/ tracer, (45')	1100 7848



Ordering Information:

		VZ ID #
400440DD-01	Dual 440D to Dual 440D w/ tracer, (1')	8727 0227
400440DD-03	Dual 440D to Dual 440D w/ tracer, (3')	8725 8439
400440DD-05	Dual 440D to Dual 440D w/ tracer, (5')	1100 7852
400440DD-07	Dual 440D to Dual 440D w/ tracer, (7')	8725 6800
400440DD-09	Dual 440D to Dual 440D w/ tracer, (9')	5700 8378
400440DD-10	Dual 440D to Dual 440D w/ tracer, (10')	1108 9987
400440DD-15	Dual 440D to Dual 440D w/ tracer, (15')	8721 8524
400440DD-20	Dual 440D to Dual 440D w/ tracer, (20')	1108 9988
400440DD-25	Dual 440D to Dual 440D w/ tracer, (25')	8721 8527
400440DD-30	Dual 440D to Dual 440D w/ tracer, (30')	1108 9989
400440DD-35	Dual 440D to Dual 440D w/ tracer, (35')	1100 7857
400440DD-40	Dual 440D to Dual 440D w/ tracer, (40')	8726 0897
400440DD-45	Dual 440D to Dual 440D w/ tracer, (45')	1100 7859
400440DD-50	Dual 440D to Dual 440D w/ tracer, (50')	8725 4584

150 Cooper Rd. (F-15)
W. Berlin, NJ 08091

www.tagcords.com

Telephone: (856) 753-8585
Fax : (856) 768-7645

Telecom Assistance Group