






FEATURES / APPLICATION	DESCRIPTION	PART #	PID #
<p><b>BNC to BNC Test Cord (75 OHM Male)</b></p> <ul style="list-style-type: none"> <li>General purpose test cord</li> <li>Available in various lengths</li> </ul> 	<p>BNC to BNC, (2')</p> <p>BNC to BNC, (5')</p> <p>BNC to BNC, (8')</p> <p>BNC to BNC, (12')</p> <p>BNC to BNC, (40')</p>	<p style="text-align: center;"><u>PART #</u></p> <p>400600-02</p> <p>400600-05</p> <p>400600-08</p> <p>400600-12</p> <p>400600-40</p>	<p style="text-align: center;"><u>AT&amp;T PID #</u></p> <p>ATT.100002467</p> <p>ATT.100002471</p> <p>ATT.100002475</p> <p>ATT.100002481</p> <p>ATT.100002527</p>
<p><b>DSX-3/4 Patch/Test Cord ("messenger") Wire</b></p> <ul style="list-style-type: none"> <li>A convenient way of patching Tx &amp; Rx circuits at the same time</li> <li>Available in various lengths</li> </ul> 	<p>LCC to BNC, (5')</p> <p>LCC to BNC, (15')</p> <p>LCC to BNC, (30')</p>	<p style="text-align: center;"><u>PART #</u></p> <p>400470B-05</p> <p>400470B-15</p> <p>400470B-30</p>	<p style="text-align: center;"><u>SOUTHEAST</u></p> <p>ATT.100002531</p> <p>ATT.100015137</p> <p>ATT.100015138</p>
	<p>440A to 358A, (12')</p>	<p style="text-align: center;"><u>PART #</u></p> <p>B40358A-12</p>	<p style="text-align: center;"><u>12 STATE</u></p> <p>ATT.100041992</p> <p style="text-align: center;"><u>SOUTHEAST</u></p> <p>ATT.100000775</p>
	<p>358A to 358A, (12')</p>	<p style="text-align: center;"><u>PART #</u></p> <p>B00358A-12</p>	<p style="text-align: center;"><u>12 STATE</u></p> <p>ATT.100038136</p> <p style="text-align: center;"><u>SOUTHEAST</u></p> <p>ATT.100000777</p>
	<p>358A to BNC, (12')</p>	<p style="text-align: center;"><u>PART #</u></p> <p>B00358B-12</p>	<p style="text-align: center;"><u>12 STATE</u></p> <p>ATT.100041987</p> <p style="text-align: center;"><u>SOUTHEAST</u></p> <p>ATT.100000759</p>