




FEATURES / APPLICATION	PART #	DESCRIPTION
<p>Dual BNC Coax Loopback Tool</p> <ul style="list-style-type: none"> Used to verify Dual BNC Coax cabling 	<p>400600LPT</p> <p>AT&T PID # ATT.100001433</p>	<p>DUAL BNC COAX LOOPBACK TOOL</p>  <p>FRONT BACK</p>
<p>358A Coax Loopback Tool</p> <ul style="list-style-type: none"> Used to verify 358A Coax cabling 	<p>400358LPT</p> <p>AT&T PID # ATT.100001435</p>	<p>358A COAX LOOPBACK TOOL</p> 
<p>Dual Mini-SMB (F) (RA) to Dual BNC, (20')</p> <ul style="list-style-type: none"> Used to extend Coax cabling for IFITL and DFITL ADSL equipment 	<p>400631D-20</p> <p>12 STATE ATT.100041975</p> <p>SOUTHEAST ATT.100001427</p>	<p>DUAL MINI-SMB (Female) (Right Angle) to DUAL BNC</p> 
<p>Dual Mini-SMB (F) (RA) to Dual Mini-SMB (F) (RA), (20')</p> <ul style="list-style-type: none"> Used to extend Coax cabling for IFITL and DFITL ADSL equipment 	<p>400630D-20</p> <p>12 STATE ATT.100053342</p> <p>SOUTHEAST ATT.100001429</p>	<p>DUAL MINI-SMB (Female) (Right Angle) to DUAL MINI-SMB (Female) (Right Angle)</p> 